

## ITEM DESCRIPTION

# MAIN PRODUCTS

**B 1 6 - 2 5 1 S**

### SYMBOL ①

#### Product

A = Highway  
**B = Offroad**  
E = Spacing tube  
G = Top-Bar  
H = Light-Bar / X-Bar  
K = X-Light  
M = Cabin ladder  
J = Safety Bar  
P = Rear Light-Bar

### SYMBOL ②

#### Trux brand

**1 = Volvo**  
2 = Scania  
4 = Mercedes  
5 = Iveco  
6 = Daf  
7 = MAN  
8 = Mitsubishi  
9 = Renault

### SYMBOL ③

#### AND/OR ④

#### Truck model Cabin model

### SYMBOL ⑤

#### Surface treatment

4 = Unprocessed (raw)  
**5 = Anodized**  
6 = White powder coating  
7 = Black powder coating  
8 = Sandblasted  
9 = Wet paint

### SYMBOL ⑥

#### 1 = Complete with accessories

2 = Without  
accessories

### SYMBOL ⑦

LF = Light Force lights  
**S = Smooth tubes**  
(where both Airflow and  
smooth are available)

**Trux**®  
*Always in the frontline*